



AIR FORCE NO. 1

—— Somatosensory Equipment
《Site requirements》

Catalog

- 1.Site requirements
- 2.Safety fence requirements
- 3.Electricity requirements
- 4.Other requirements

1. Site requirements

1.1 Enter site requirements

The size of the equipment is about 2.4m*2.1m*2.5m (length * width * height), Because of the particularity of the equipment, it is inconvenient to assemble and disassemble, so the entrance, elevator or door size must be 20 centimeters more than the size of the equipment itself. And you need to prepare forklift trucks with 2m forks to unload, install, and move .

1.2 Placed venue requirements

1.2.1 size requirements:

According to the size of the product, because the equipment is A, B, C three 360 degree rotation, so the size of the space required for a single device should not be less than 3.4m*3m*3.5m (length * width * height).

1.2.2 Other requirements:

Because the equipment needs to connect AC power for operation, need waterproof, and try to avoid damp and insolation, generally recommend indoor installation operation.

2. Safety fence requirements

Because of the relatively large operating angle of the equipment, safety barriers must be set up within 1 meter of the product safety distance, and should be set separately for export and export, with the necessary anti-skid measures.

3. Electricity requirements

Power: single phase 6 – 7.5KW, air switch 30 – 35A (single one), voltage: 220V.

4. Other requirements

Conspicuous safety signs should be set up in necessary places and places.